

# Installation Guide For Clear Blue<sup>®</sup> PCO System

1. Secure this template on the duct in the appropriate location
2. Drill and cut out where indicated
3. Mount the Clear Blue<sup>®</sup> PCO System using the supplied black screws. **DO NOT USE THE SCREWS SUPPLIED WITH THE Clear Blue<sup>®</sup> Master**



Drill



Cut out



Air Flow

### WARNING

Use a vacuum or forced air to clean the PCO module. Do not submerge in water.

### WARNING

Before installing or performing maintenance or service on the purifier, **DISCONNECT** from main power. Electrical shock can cause injury or death.

### WARNING

Never expose eyes or skin to ultraviolet light from any source. The Purifier **MUST** be **DISCONNECTED** from power source before performing maintenance or service. Personal injury may result.

### WARNING

Do not touch Lamp glass without gloves. Reduced performance of Lamp may result. Clean Lamp after handling with isopropyl alcohol.

### WARNING

The UV Lamp contains a small quantity of mercury. If a Lamp breaks, clean and dispose of with care.

### WARNING

Use only specified replacement Lamps with your Purifier. Use of an incorrect Lamp can result in damage to the Purifier and/or Lamp. Lamp part #: UUVS-LP160T5

